



SAMPLE WOOD TRU	SS ATTACHED	TO FASTBLOC	1/2
-----------------	-------------	-------------	-----

CONSTRUCTION SHALL BE IN ACCORDANCE WITH ALL APPLICABLE LOCAL AND NATIONAL CODES. ALL DRAWINGS ARE FOR EXAMPLE PURPOSES AND ARE TO BE USED AS A REFERENCE GUIDE ONLY.

18/03/07

DATE/REV